


3 IN 1 SPORTS CENTRE

Enjoying the product?
Tag @pregobabymalaysia on
Facebook and Instagram to share
your moments.





Prego Manufacturing Warranty

Visit www.pregobaby.com.my/warranty-registration to register your product warranty

ATTENTION!

We strongly advise you to read all instructions before assembly and use. If you have concern or question, please contact Prego customer service on www.pregobaby.com.my


IMPORTANT!

- 1. Adult assembly required.
- 2. Please read all instructions before assembly and use of the product.
- 3. Care should be taken in unpacking and assembly.
- 4. Examine product frequently for damaged, missing or loose parts.
- 5. DO NOT use if any parts are missing, damaged or broken.


WARNING!


- 1 Please wipe and clean sports centre with mild soap before use.
- 2. Keep all children away during assembly.
- 3. This product is suitable for children 3 years and above.
- 4. This product is for indoor use only.
- 5. Always place the product on a flat and level surface.
- 6. To avoid serious injury, never use the product near stairs, steps or uneven surface.
- 7. Never allow children to climb on the product.
- 8. Make sure all screws are secured.
- 9. Keep away from high temperature objects, liquids and electronics.

WHAT'S IN THE BOX



ASSEMBLY GUIDE





NOTE!

Use screwdriver provided to tighten or loosen the nuts.

CARE AND MAINTENANCE

- Sports centre can be wiped and cleaned with damp cloth and soapy water. Do not use aggressive cleaning agents to clean the playpen.
- From time to time check the product for loose screws, worn parts, torn material or stitching. Replace or repair the parts as needed.
- 3. Avoid placing sports centre under direct sunlight. Excessive exposure to sun or heat could cause fading or warping of parts.